

Task: Disconnect, remove, and crate up FPP wire chambers

Task #: C-08-23-T

Date: 6-23-08

Complete all information. Use as many sheets as necessary.	
Task location: Hall C	Frequency of use: Once
Division: PHY	Prepared by: J Nines
Department: Hall C	Reviewed by (employee): <i>C. Kossuth</i>
Supervisor: W. Kellner	Approved by: <i>[Signature]</i>
Standard Requirements: (PPE, TOSPs, SOPs, etc.) Hardhats, safety shoes, gloves. Journeyman rigger and crane operator. Follow standard rigging procedures and EH&S 6140 Crane & Hoist, 6147 Aerial Work Platforms, 6132 Ladders and Scaffolds, 6145 Fork Lift, and 6131 Trip and Fall Protection	

Sequence of Job Steps	Potential Hazards	Risk Code before mitigation	Safety Procedures/Practices/Controls	Risk Code after mitigation
Notify RADCON to have them survey wire chambers	Contamination/activation	1	Survey chambers when they leave hall	0
Attach installation fixture to crane	Pinch fingers	1	Journeyman rigger to use gloves	0
Position fixture enabling attachment to chambers	Injury, property damage, due to collision	1	Certified crane operator will make slow moves and use spotter to clear path	0
Attach chambers to fixture	Pinch fingers	1	Journeyman rigger to use gloves	0
Crane chambers down to awaiting shipping crate	Injury, property damage, due to collision	1	Certified crane operator will make slow moves and use spotter to clear path	0
Lower chambers into shipping crate and unrig from crane	Pinch fingers	1	Journeyman rigger to use gloves And have helpers if necessary	0
Cover shipping crate	Pinch fingers	1	Use gloves be careful.	0

When a completed analysis indicates that the estimated risk code for any of the steps of this task is "medium" or higher (RC≥3), then develop a formal written procedure for the task and have it reviewed and approved prior to beginning the work.